

STARTING YOUR RIDE

1. 360° Inspection

Start with a 360° visual inspection of the Coaster ECT before each ride. Check for any obstructions in your path, inspect tires for proper inflation, and ensure all doors are securely closed.

2. Adjust

Adjust your saddle height with the quick release located on the seat post collar. Never extend post past the minimum insertion line.

Adjust mirrors (AW Models only) to maximize sight lines and reduce blind spots.

3. Install Battery

Verify the battery (a) is secure and fully charged before riding.

For models with secondary lighting, be sure the 12 volt auxiliary battery (b) is charged and installed properly.

4. Power

Power on the lighting and electrical system by passing the blue keyfob over the RFID receiver (e) located in the right-hand corner of the rider cockpit.

Note: The Venture and Freighter do not need the RFID key to start.

5. Brake Release

1. Unlock the front frame lock (c - located around the front wheel).
2. Unlock the front parking brake by compressing the lever to release lock.
3. Release the rear parking brake by compressing until the lock releases.

6. Riding Mode

Turn on the power to the computer (d). Adjust to preferred mode using the "+" and "-" keys on the controller while in a stable position.

Models with automatic shifting automatically adjust with your preferred cadence.

7. Get Moving

Sit on the saddle with both hands on the handlebars and both feet on the pedals.

Use your signals (hands and/or lights) to pull into the bike lane or roadway. Lastly, enjoy your day!

For more information and to read our Owner's Manual, visit us at www.coastercycles.com/support



STOPPING FOR DELIVERY

1. Parking

Find a stable place to park your Coaster ECT out of the line of traffic and walkways.

2. Braking

1. Compress the front brake and turn the lock counterclockwise.
2. Compress the rear brake and engage the parking lever.
3. Engage the frame lock (c) around the front wheel.

3. Delivery

1. Unlock cargo doors and grab parcel.
2. Close and lock the Cargo door and all other compartments (12 volt auxiliary battery (b) and rider gear storage compartments).
3. Take any electronics from the cockpit (d) (cell phone and computer).
4. Swipe the blue keyfob over the RFID reader (e) to arm the anti-theft system (if applicable to Coaster model).

4. After Delivery

1. Swipe the blue keyfob to disarm your anti-theft system (e).
2. Attach computer (d) and other electronics.
3. Verify eAssist mode.
4. Use hand signals or turn signals to enter on to roadway.



FINISHING YOUR RIDE

1. Parking

Find a secure place to park your Coaster ECT out of pedestrian and vehicle traffic. When possible, reverse park for safe maneuvering and exiting for your next ride.

2. Braking

1. Compress the front brake and turn the lock counterclockwise.
2. Compress the rear brake and engage the parking lever.
3. Engage the frame lock (c) around the front wheel

3. Cargo lock

Close and lock all cargo doors and auxiliary doors behind the driver with the designated key on the keyfob keyring.

4. Battery Charging

Turn off the Bosch battery (a) and remove it from the battery holder. In a safe and well-ventilated area, plug it into the charger.

The Parcel and Freighter AW models have an anti-theft system installed. This system is powered by a 12 volt auxiliary battery (b) located on the lower part of the cargo box on the driver's right side. This battery should be charged daily but could be used overnight to keep the anti-theft armed. Always verify this battery is charged before starting the next day.

5. Power Down

Whether arming the anti-theft system or taking the 12 volt battery (b) out to charge, swipe the blue keyfob over the RFID reader (e). Store keyfob keyring in a designated and safe place for tomorrow's ride.